

VOLA 090, 090A, 090B:
VOLA 090C, 090D, 090E:
VOLA 090G, 090H, 090I, 090V:

1 - 4

VOLA 090FM:


5

Fitting instruction
Montageanleitung
Monteringsvejledning

Monteringsvægledning
Montage hanleiding
Manuel de montage




04/00045
04/00109



www.vola.com



vola

mnt_090_V4_40999824
21-11-2023




mm:	Ø	H	D	h
090	19	210	200	145
090A	19	110	85	40
090B	19	185	100	114
090C	24	185	100	114
090D	24	220	200	130
090E	24	170	200	65
090G	19	185	140	105
090H	19	265	220	155
090I	19	325	220	215
090V	19	355	145	270


Inches:	Ø	H	D	h
090	3/4"	8 1/4"	8"	5 3/4"
090A	3/4"	4 1/4"	3 1/2"	1 1/2"
090B	3/4"	7"	4"	4 1/2"
090C	1"	7"	4"	4 1/2"
090D	1"	8 3/4"	8"	5"
090E	1"	6 3/4"	8"	2 1/2"
090G	3/4"	7"	5 1/2"	4"
090H	3/4"	10 1/2"	8 5/8"	6"
090I	3/4"	12 3/4"	8 5/8"	8 1/2"
090V	3/4"	14"	5 3/4"	10 1/2"




Ø19: (VR38)
090A



Ø19-40: (VR38A)
090A




Ø19: (VR38L)
090
090B
090G
090H
090I
090V




Ø19-40: (VR38)

090
090B
090G
090H
090I
090V





Ø24: (VR638)


090C
090D
090E




Ø24-40: (VR633)


090C
090D
090E







VR17L9K: VR15P, VR16L9, VR17L
 VR17LSK: VR15P, VR16LS, VR17L
 VR17LXK: VR15P, VR16LX, VR17L
 VR090L9: VR15P, VR16L9, VR17L, 2xVR18, 2xVR31, VR1902
 VR437: VR98, 2xVR444, VR450, VR451



vola

Lunavej 2
 DK-8700 Horsens
 Tlf : + 45 7023 5500
 sales@vola.com
 www.vola.com

VOLA 090

Date
 Okt. 16

Rev.
 3

Sheet
 SB 18